




**1** Click on the **CAMERA** to check installation bracket




**2** Click **HERE** to check full bracket system




## For DI-VF Lens, DI-MVF Lens & DH-Fixed Lens, DH-MVF Lens



## For DAI-Fixed Lens




\* Please remove the junction box cover **BEFORE** connect the camera to the junction box.




## For DAI-VF Lens, DAI-MVF Lens




\* Please remove the junction box cover **BEFORE** connect the camera to the junction box.



## For DMA



## For FEI



For DI-AB



For I1-AB



+



**IP65**



PR-B42PJB+




## For I5PT / I8PT





## For Bullet I6-VF Lens, I6-MVF Lens



+



+




# For I4-Fixed Lens, I4-VF Lens, I4-MVF Lens, BMV-Fixed Lens & BMH-Fixed Lens, BMH-MVF Lens




+




+






## For I2-Fixed Lens & BSV-Fixed Lens



+



+



## For PTZ-Z4




+



+






+



+

+




## For PTZ-Z5



+





+



+

+




## For PTZ-Z6



+





+



+

+





# Junction boxes



Model	Junction boxes	Installation
<b>Dome</b> DI-VF	Wall A PR-WB-A OR IP66 PR-JB14IP66 IP64 PR-JB14IP64	Wall B optional PR-WB14 PR-B10EX Ceiling optional PR-CB14 PR-B10EX Pole optional PR-B50PB PR-WB14 Corner optional PR-B50ECB PR-WB14
<b>Dome</b> DI-FIX	Wall A PR-WB-A OR IP66 PR-JB12IP66 IP64 PR-JB12IP64	Wall B optional PR-WB12 PR-B10EX Ceiling optional PR-CB12 PR-B10EX Pole optional PR-B50PB PR-WB12 Corner optional PR-B50ECB PR-WB12
<b>Dome</b> DAI-VF	IP66 PR-JB14IP66 *	Wall optional PR-WB14 PR-B10EX Ceiling optional PR-CB14 PR-B10EX Pole optional PR-B50PB PR-WB14 Corner optional PR-B50ECB PR-WB14 OR Ceiling PR-ICB23
<b>Dome</b> DAI-FIX	Wall A PR-WB-A OR IP66 PR-JB12IP66 *	Wall B optional PR-WB12 PR-B10EX Ceiling optional PR-CB12 PR-B10EX Pole optional PR-B50PB PR-WB12 Corner optional PR-B50ECB PR-WB12 OR Ceiling PR-ICB21
<b>Dome</b> DMA	Wall A PR-WB-A OR PR-B10BJB	Wall B optional PR-WB12 PR-B10EX Ceiling optional PR-CB12 PR-B10EX
<b>Dome</b> FEI	IP66 PR-B50JB OR Wall optional PR-WB50 PR-B10EX Ceiling optional PR-CB50 PR-B10EX	

**\* For DAI Installations, please remove the junctions box cover and connect the camera directly to the junction box**

Model	Junction boxes	Installation
<b>Bullet</b> I6	IP66 PR-JB14IP66 IP64 PR-JB14IP64	Wall optional PR-WB14 PR-B10EX Ceiling optional PR-CB14 PR-B10EX Pole optional PR-B50PB PR-CB14 Corner optional PR-B50ECB PR-CB14
<b>Bullet</b> I4	IP66 PR-JB12IP66 IP64 PR-JB12IP64	Wall optional PR-WB12 PR-B10EX Ceiling optional PR-CB12 PR-B10EX Pole optional PR-B50PB PR-CB12 Corner optional PR-B50ECB PR-CB12
<b>Bullet</b> I2	IP66 PR-JB12IP66 IP64 PR-JB12IP64	Wall optional PR-WB12 PR-B10EX Ceiling optional PR-CB12 PR-B10EX Pole optional PR-B50PB PR-CB12 Corner optional PR-B50ECB PR-CB12
<b>PTZ</b> Z4	Wall INCLUDED OR PR-WJB-Z Integrated Junction Box Ceiling PR-CB-Z In-Ceiling PR-ICB-Z Pole PR-B50PB INCLUDED Corner PR-B50ECB INCLUDED Pole PR-B60PB PR-WJB-Z Corner PR-B60ECB PR-WJB-Z	
<b>PTZ</b> Z5	Wall INCLUDED OR PR-WJB-Z Integrated Junction Box Ceiling PR-CB-Z Pole PR-B50PB INCLUDED Corner PR-B50ECB INCLUDED Pole PR-B60PB PR-WJB-Z Corner PR-B60ECB PR-WJB-Z	
<b>PTZ</b> Z6	Wall INCLUDED OR PR-WJB-Z Integrated Junction Box Ceiling PR-CB-Z Pole PR-B70PB INCLUDED Corner PR-B70ECB INCLUDED Pole PR-B60PB PR-WJB-Z Corner PR-B60ECB PR-WJB-Z	